



LOGIMEC

Industrial Ultrasonic Cleaning
Jewelry manufacturing equipment



TECHNICAL SHEET

MODELLO E5004

Steam jets are a very effective method of cleaning for restoring shine to samples, cleaning models to remove wax residues, and eliminating traces of oxidants left by welding.

In the dentistry field this method is widely used for the decontamination of metal bridges, cleaning models, washing instruments and eliminating residues of the casting process. In general, saturated steam is also suitable for brightening objects, since the items always remain completely dry. Our steam jet cleaners are able to produce "saturated" steam, that is absolutely moisture-free, at a 6 bar pressure. This is essential for rapid in-depth cleaning. Our steam jet cleaners are reliable and safe, extremely compact, useful in thousands of different applications

E 5004

It is the most complete version of our steam jet cleaners. It is provided with an electronic control of the water level and an inside pump which automatically provides to load the boiler taking water from the tank built into the top of the machine. A flashing light and an outside alarm indicate to the operator the need to provide to refill water in the tank. This method allows to work without limits since, the external tank, can be filled of water even when the machine is under pressure. E5004 is the right machine for those who require a non-stop service for refilling.

Main features

- ✓ Safe and easy to use.
- ✓ Rapid, in-depth cleaning with saturated steam.
- ✓ Practical foot-control lever for the coming out of the steam.
- ✓ Automatic control of boiler water level.

E5004	MEASURES	VALUES	LENGTH	WIDTH	HEIGHT
EXTERNAL DIMENSIONS	MM		250	490	450
MAX STEAM PRESSURE	BAR	6			
BOILER CAPACITY	LT	4.8			
HEATING POWER	W	2000			
SUPPLY VOLTAGE	V	220	HZ	50/60	
WEIGHT	KG	19.5			